



N10/1 Front SAM control unit with fuse X Direction of travel and relay module

Socket	Designation
J	Terminal 15 relay (N10/1kJ)
К	Terminal 15R relay (N10/1kK)
LL	<ul> <li>Wiper park heater relay (N10/1kL)</li> </ul>
М	<ul> <li>Circuit 50 starter relay (N10/1kM)</li> </ul>
0	Engine circuit 87 relay (N10/1kN)
0	Fanfare horn relay (N10/1kO)
Р	Valid for engine 272: • Secondary air injection relay (N10/1kP)
Q	Backup relay (N10/1kQ)
R	Chassis circuit 87 relay (N10/1kR)

P54.15-3021-09