MODEL 212.0 with CODE (224) Design individual rear seat system


Shown on right side of vehicle, vehicle with code (872) Electric seat heater for left and right rear seat

1 Rear seat cushion

2 Support

X54/11

Left and right rear seat heater heater pad electrical connector (with code (872) Electric seat heater for left and right rear seat)



P91.12-3470-06

X	Remove/install		
1	Adjust front seat forward		
2	Pull rear seat cushion (1) upwards out of guide sleeves (arrows)		
3	Slide back rear seat cushion (1) until retaining bracket on bottom of rear seat cushion (1) is guided out of mount (2)	i Installation: Ensure that retaining bracket on bottom of rear seat cushion (1) is seated correctly in mount (2).	
4	Guide rear seat cushion (1) forward and disconnect left or right rear seat heater heater pad electrical connector (X54/11)	For vehicles with code (872) Electrically heated left and right rear seats	
5	Remove rear seat cushion (1)	Remove rear seat cushion (1) from the vehicle carefully, to avoid damage to components in the vehicle interior or on the rear doors.	
6	Install in the reverse order		