



Date: February 9, 2015
Order No.: S-B-15.10/74
Group: 15

SUBJECT: Engines 104, 111, 112, 113, 119, 120, 133, 137, 152, 155, 156, 157, 159, 166, 266, 270, 271, 272, 273, 274, 275, 276, 277, 278, 279, 285

Spark Plug Connector Grease

To reduce the force required to plug or unplug the spark plug connector, apply grease before installing the spark plug connector. Otherwise, the spark plug connector may be damaged when it is removed at another time. Other greases are not permitted. Apply approximately one gram of the spark plug connector grease uniformly into the spark plug connector as shown in the Figure 1.



Figure 1. Applying grease. P15.10-2553-02

Parts Information

Qty.	Part Name	Part Number
1	Spark plug connector grease	A 002 989 80 51

This bulletin has been created and maintained in accordance with MBUSA-SLP S423QH001, Document and Data Control, and MBUSA-SLP S424HH001, Control of Records.