



# Mercedes NTG4.5 Wireless CarPlay installation diagram



Dip switch	Status	Description
1	ON	NTG4.5 5.8"(480*234)
	OFF	NTG4.5 7"(800*480)
4	ON	Reverse guideline OFF
	OFF	Reverse guideline ON
6	ON	RGB mode
	OFF	CVBS mode (default)
8	ON	Original camera
	OFF	Aftermarket camera

2, 3, 5, 7 no function, default OFF.



Joystick knob controls

Press "C" use Siri

Long press "Back" switch to CarPlay, short press use return

Select AUX before switch to CarPlay