



DTCs. Finding P24AF and P2463, I tried replacing the Soot Sensor. These codes remained and then P2463 appeared. I reset and drove over an hour. Car went into Limp Home mode. Replaced old sensor and new code remains with LHM too. :(



Exhaust pipe. Note: Wood block are not supporting (just cheap insurance). :D Exhaust pipe showing SCR and CAT?



SCR





CAT?



DPF?



Fuel injection into exhaust for DPF regen?