

MODEL 207






P54.35-2206-09

1 Nut
2 Bracket

3 Electrical connections
H2 Left fanfare horn

H2/1 Right fanfare horn

	Remove/install		
1.1	Remove front engine compartment paneling	MODEL 207 with ENGINE 271, 272, 273, 274, 276, 278	AR61.20-P-1105EW
1.2	Remove bottom section of soundproofing at front	MODEL 207 with ENGINE 642, 651	AR94.30-P-5300EW
2	Disconnect electrical connectors (3) from left horn (H2) or right horn (H2/1)		
3	Unscrew nut (1) and remove left horn (H2) or right horn (H2/1) from bracket (2)	<p> Installation: Align the left horn (H2) or right horn (H2/1) so that the trumpet points downward at an angle. This prevents a buildup of liquid and allows any moisture inside to drip off.</p> <p> Installation: Place the left horn (H2) or right horn (H2/1) in the original position on the bracket (2). If the left horn (H2) or right horn (H2/1) is to be replaced, the bracket (2) included in the package contents must be detached from the new left horn (H2) or right horn (H2/1).</p>	
4	Install in the reverse order		