

Item	Designation	Coordinates
<u>A0</u>	Color code key	96L
<u>Code 581</u>	Automatic air conditioning	69G
<u>Code U42</u>	BlueTEC diesel exhaust treatment	60J
<u>Code U77</u>	BLUETEC (SCR) diesel exhaust treatment	60J
<u>K40/10</u>	HYBRID fuse and relay module	48L
<u>N3/9</u>	CDI control unit	19L 26L
<u>N3/10</u>	ME-SFI [ME] control unit	7L 11L 15L 31L
<u>N10/1</u>	Front SAM control unit with fuse and relay module	20A 29A 37A 44A 53A 61A 68A 76A 85A 91A
<u>N10/1f1</u>	Fuse 1	69A
<u>N10/1f2</u>	Fuse 2	84A
<u>N10/1f3</u>	Fuse 3	77A
<u>N10/1f6</u>	Fuse 6	15A
<u>N10/1f7</u>	Fuse 7	17A
<u>N10/1f9</u>	Fuse 9	89A
<u>N10/1f14</u>	Fuse 14	66A
<u>N10/1f20</u>	Fuse 20	67A
<u>N10/1f25</u>	Fuse 25	45A
<u>N10/1kM</u>	Starter circuit 50 relay	18A
<u>N30/4</u>	Electronic Stability Program control unit	67L 67L
<u>N30/7</u>	Premium Electronic Stability Program control unit	66L 68L
<u>N69/1</u>	Left front door control unit	82L
<u>N69/2</u>	Right front door control unit	74L
<u>N69/3</u>	Left rear door control unit	86L
<u>N69/4</u>	Right rear door control unit	78L
<u>N118/2</u>	CNG control unit	3L
<u>U12</u>	Valid for left-hand drive vehicles	66G 73G

Item	Designation	Coordinates
<u>U13</u>	Valid for right-hand drive vehicles	76G 80G 90J
<u>U1018</u>	Valid for gasoline engine 276	69G 73G 80G 84G 90K
<u>U1027</u>	Valid for gasoline engine 271 continuous fuel injection system (electronic)	13G 42J 56J
<u>U1032</u>	Valid for engine 278 and 157	1G 35G 40J
<u>U107</u>	Valid for socket in glove compartment	13G 42J 57J
<u>U113</u>	Valid for 2-zone THERMATIC	88G
<u>U127</u>	Valid for combustion engines 272 and 273 KE	69G
<u>U152</u>	Valid for combustion engines 272 and 273 KE	1G 33G 39J 53J
<u>U157</u>	Valid for gasoline engine 156	1G 33G 39J 45G 53J
<u>U243</u>	Valid for combustion engine 272 DE	9G 33G 40J 54J
<u>U244</u>	Valid for diesel engine 651 with all-wheel drive	51J
<u>U249</u>	Valid for BlueTEC	22G 22G
<u>U252</u>	Valid for diesel engine 651 without all-wheel drive	51J
<u>U561</u>	Valid for ECO start/stop function	20H
<u>U562</u>	Valid for Delphi system	22G
<u>U739</u>	Valid for Bosch system	22G
<u>U880</u>	Valid for gasoline engine 271 DE	29G 39J 54J
<u>U880</u>	Valid for diesel engine 642	17G 35G 36J

Item	Designation	Coordinates
		50J
<u>U938</u>	Valid for ESP Basic	62G 63G
<u>U939</u>	Valid for ESP Premium	63G 63G
<u>U948</u>	Valid for diesel engine 651	17G 21G 21G 35G 36J 51J
<u>U968</u>	Valid for mild hybrid drive	46G
<u>W15/5</u>	Left front footwell ground point	91L
<u>W15/7</u>	Right front footwell ground point	91L
<u>X18</u>	Vehicle interior and harness for taillamp electrical connector	89H
<u>X26</u>	Interior and engine wiring harness electrical connector	45J
<u>X35/3</u>	Left rear door electrical connector	86J
<u>X35/4</u>	Right rear door electrical connector	78J
<u>X58/31</u>	Glove box socket	89L
<u>Z3z1</u>	Tml. 15 connector sleeve	23L
<u>Z7/35z1</u>	Circuit 87 M1e connector sleeve	35L
<u>Z7/98z3</u>	Circuit 87 M3e connector sleeve	46L