

Item	Designation	Coordinates
<u>A0</u>	Color code key	72L
<u>A26/1</u>	Driver-side front door infrared remote control receiver	27L
<u>A85</u>	Left front door lock	20L 23L
<u>A85m1</u>	Left front door central locking motor	19L 22L
<u>A85m4</u>	Left front door additional door lock actuator motor	25L
<u>A85s1</u>	Left front door rotary tumbler switch	20L 23L
<u>Code 889</u>	KEYLESS-GO	18E
<u>E6/5</u>	Left outside mirror turn signal lamp	55L
<u>E6/5x1</u>	Left outside mirror turn signal lamp electrical connector	54H
<u>E17/3</u>	Left front door exit and warning lamp	47L
<u>E17/11</u>	Left front door door handle illumination	46L
<u>E17/43</u>	Left front door ambiance illumination	49L 51L
<u>M10/3</u>	Left front door power window motor	16L
<u>M21/1</u>	Left outside mirror	58L
<u>M21/1e1</u>	Left outside mirror ambient lamp	69L
<u>M21/1e2</u>	Left Blind Spot Assist readiness and warning indicator	67L
<u>M21/1e2x1</u>	Blind Spot Assist warning lamp/left mirror dimming electrical connector	64H
<u>M21/1h1</u>	Automatic dimming mirror	63L 65L
<u>M21/1h1x1</u>	Mirror dimming electrical connector	62H
<u>M21/1m1</u>	Vertical inclination adjustment actuator motor	58K
<u>M21/1m2</u>	Horizontal inclination adjustment actuator motor	58K
<u>M21/1m3</u>	Outside mirror fold-in/fold-out electric motor	61L
<u>M21/1r1</u>	Mirror heater	56L
<u>M21/1r2</u>	Vertical inclination adjustment potentiometer	59K
<u>M21/1r3</u>	Horizontal inclination adjustment potentiometer	59K
<u>N10/1</u>	Front SAM control unit with fuse and relay module	9L
<u>N10/1f2</u>	Fuse 2	7L
<u>N10/2</u>	Rear SAM control unit with fuse and relay module	3L
<u>N10/2f39</u>	Fuse 39	2L
<u>N69/1</u>	Left front door control unit	4A 12A 19A 28A 37A 45A 54A

Item	Designation	Coordinates
		62A 70A
<u>S15/1</u>	Trunk lid release button	40L
<u>S15/3</u>	Driver trunk lid/liftgate control button	40L
<u>S20</u>	Driver-side power window and outside mirror adjustment switch group	32L
<u>S20s1</u>	Left front power window switch	28L
<u>S20s2</u>	Right front power window switch	29L
<u>S20s3</u>	Left rear power window switch	31L
<u>S20s4</u>	Right rear power window switch	32L
<u>S20s5</u>	Rear side window child safety lock switch	30L
<u>S20s9</u>	Outside mirror fold-in/fold-out switch	34L
<u>S20s10</u>	Left outside mirror adjustment switch	35L
<u>S20s11</u>	Right outside mirror adjustment switch	36L
<u>S20s12</u>	Outside mirror adjustment switch	33L
<u>S21/2</u>	Passenger-side power window switch	43L
<u>S22</u>	Left front seat adjustment switch group	53L
<u>S85/5</u>	Left front door central locking interior switch	38L
<u>U12</u>	Valid for left-hand drive vehicles	5E 10C 26E 39E 62E 64E
<u>U13</u>	Valid for right-hand drive vehicles	1E 5E 42E
<u>U57</u>	Valid for model 212.2	39E
<u>U58</u>	Valid for model 212.0/1	39E
<u>U71</u>	Valid for fully electric seat adjustment with memory function	52E 58E
<u>U76</u>	Valid for automatic dimming mirror	62E 64E
<u>U144</u>	Valid for outside mirror fold-in/out function	34J 60E
<u>U344</u>	Valid for all except KEYLESS GO	21E
<u>U416</u>	Valid for one-color ambiance illumination	48A
<u>U417</u>	Valid for three-color ambiance illumination	50A
<u>U897</u>	Valid for intelligent servo module for DIRECT SELECT	10D
<u>U910</u>	Valid for Blind Spot Assist	64E
<u>U921</u>	Not valid for England	18E
<u>U928</u>	Valid for England	21E

Item	Designation	Coordinates
		24F
<u>U951</u>	Valid for ambient lamps	68E
<u>W15/2</u>	Left footwell ground point	8D
<u>X30/32</u>	Left vehicle floor interior CAN voltage distributor electrical connector	13L
<u>CAN B</u>	Interior CAN	13K
<u>LIN B5</u>	Left front door LIN	28B 52B