
GF32.33-P-0004-06FL	Electronic rear axle level control, location of	
	components	

Model 212.2

except code 488 (Steel/air suspension)

except code 489 (AIRMATIC Dual Control/semi-active air suspension)



P32.33-2024-79

A1	Instrument cluster	N3/9	CDI control unit (with diesel engine)	N30/7	Premium Electronic Stability Program control unit (with CODE 233 (DISTRONIC PLUS) or with CODE 990 (AMG vehicles), except hybrid)
A9/1	AIRMATIC compressor	N3/10	ME-SFI [ME] control unit (with gasoline engine)	N49	Steering angle sensor
A9/1y1	AIRMATIC pressure reduction valve	N10/1	Front SAM control unit with fuse and relay module	N80	Steering column module control unit
B22/7	Left rear level sensor	N10/2	Rear SAM control unit with fuse and relay module	N97	Rear axle electronic level control control unit
B22/10	Right rear level sensor	N30/4	Electronic Stability Program control unit (except CODE 233 (DISTRONIC PLUS), except CODE 990 (AMG vehicles), except hybrid)	Y36/8	Electronic level control level control valve
K67	AIRMATIC relay	N30/6	Regenerative braking system control unit (for hybrid)		