

<b>Item</b>	<b>Designation</b>	<b>Coordinates</b>
<b><u>A0</u></b>	Color code key	48L
<b><u>B22/8</u></b>	Left front level sensor	2L
<b><u>E1</u></b>	Left front lamp unit	4L 12L 27L 33L
<b><u>E1e1</u></b>	Left high beam	27L
<b><u>E1e2</u></b>	Left low beam	28L
<b><u>E1e3</u></b>	Left front standing and parking lamp	14L 29L
<b><u>E1e5</u></b>	Left front turn signal lamp	14L 29L
<b><u>E1e10</u></b>	Left xenon bulb with integrated ignition module	13L
<b><u>E1e11</u></b>	Left infrared lamp	11L
<b><u>E1l1</u></b>	Left high beam solenoid	4L
<b><u>E1m1</u></b>	Left headlamp range adjustment actuator motor	5L 31L
<b><u>E1m2</u></b>	Left active curve illumination actuator motor	6L
<b><u>E1m3</u></b>	Left light distribution actuator motor	7L
<b><u>E1n1</u></b>	Left xenon lamp control unit	5L
<b><u>E2</u></b>	Right front lamp unit	18L 25L 35L 42L
<b><u>E2e1</u></b>	Right high beam	35L
<b><u>E2e2</u></b>	Right low beam	36L
<b><u>E2e3</u></b>	Right front standing and parking lamp	23L 37L
<b><u>E2e5</u></b>	Right front turn signal lamp	23L 37L
<b><u>E2e10</u></b>	Right xenon bulb with integrated ignition module	22L
<b><u>E2e11</u></b>	Right infrared lamp	24L
<b><u>E2l1</u></b>	Right high beam solenoid	18L
<b><u>E2m1</u></b>	Right headlamp range adjustment actuator motor	19L 39L
<b><u>E2m2</u></b>	Right active curve illumination actuator motor	20L
<b><u>E2m3</u></b>	Right light distribution actuator motor	21L
<b><u>E2n1</u></b>	Right xenon light control unit	19L
<b><u>N10/1</u></b>	Front SAM control unit with fuse and relay module	7A 12A 20A 28A

<b>Item</b>	<b>Designation</b>	<b>Coordinates</b>
		36A
<b><u>N10/1f29</u></b>	Fuse 29	30A
<b><u>N10/1f30</u></b>	Fuse 30	26A
<b><u>N10/1kJ</u></b>	Circuit 15 relay	28A
<b><u>U248</u></b>	Valid for headlamp range adjustment for halogen headlamps	30G 38G
<b><u>U501</u></b>	Valid for xenon headlamps	1F
<b><u>U512</u></b>	Valid for electronic level control	4G 7G
<b><u>U679</u></b>	Valid for version without xenon headlamps	26F
<b><u>U907</u></b>	Valid for Night View Assist	12G 21G
<b><u>U941</u></b>	Valid without electronic level control	5G 8G
<b><u>W2</u></b>	Right front ground point at lamp unit	26L 35H 43L
<b><u>W9</u></b>	Left front ground point (at lamp unit)	17L 27H 34L
<b><u>Z6/56</u></b>	Circuit 31 connector sleeve	16J 34J
<b><u>Z6/97</u></b>	Right lamp unit circuit 31 connector sleeve	26J 42J
<b><u>Z36/5</u></b>	Headlamp range adjustment sensor ground connector sleeve	8H
<b><u>Z36/6</u></b>	Sensor voltage supply connector sleeve	6H
<b><u>CAN G</u></b>	Front end CAN	10K 18K