

Code:	Designation:	Position:
A0	Color code key	88L
A2	Radio	24L
A2/56	Radio with auto pilot system	24L
A40/3	COMAND control unit	28L
B31	Emissions sensor	51L
B48	Front passenger seat occupied recognition and ACSR	5L
CAN D	Diagnostic CAN	32K
CAN D	Diagnostic CAN	38K
CAN E	Chassis CAN	61J
CAN E	Chassis CAN	61J
CAN E	Chassis CAN	63J
CAN E1	Chassis CAN 1	61J
CAN E1	Chassis CAN 1	63J
CAN E2	Chassis CAN 2	68K
CAN E2	Chassis CAN 2	306
Code 348	Emergency call/assistance system	346
Code 350	Ecail Europe emergency call system	306
Code 359	TELEAID emergency call system	66
Code U10	Weight sensing system (WSS)	73L
E1/3	Left daytime running lamps headlamp	12L
E1/3	Glove box lamp	75L
E2/3	Left fog lamp	81L
E3/1	Right daytime running lamps headlamp	82L
E3/1	Left fog lamp	77L
E5/1	Left fog lamp	78L
E5/2	Right fog lamp	49F
E6/1	Left front side-marker lamp	71L
E6/2	Right front side-marker lamp	12A
LN B8	Climate control LIN	5A
LN B8	Climate control LIN	22A
LN B8	Climate control LIN	29A
LN B8	Climate control LIN	36A
LN B8	Climate control LIN	44A
LN B8	Climate control LIN	61A
LN B8	Climate control LIN	69A
LN B8	Climate control LIN	77A
LN B8	Climate control LIN	82A
LN B8	Climate control LIN	52A
LN B8	Climate control LIN	20A

Code:	Designation:	Position:
N10/1f21	Fuse 21	4A
N10/1f26	Fuse 26	25A
N110	Weight Sensing System (WSS) control unit	8L
N112/2	Telematics services communication module	38L
N123/4	Emergency call system control unit	32L
N22/4	Rear air conditioning operating unit	45L
N22/7	Automatic air conditioning operating unit	41L
N22/7	Automatic air conditioning control and operating unit	49L
N22/7	Automatic air conditioning control and operating unit	54L
N26/5	Electric steering lock control unit	16L
N68	Electric power steering control unit	67L
N73	Electronic ignition switch control unit	20L
S12	Parking brake indicator switch	57L
S17/9	Glove box lamp switch	11L
S9/1	Stop lamp switch	3L
U1	Valid for USA	76A
U113	Valid for 2-zone THERMATIC	32B
U113	Valid for 2-zone THERMATIC	69B
U114	Valid for 3-zone THERMOTRONIC	40B
U114	Valid for 3-zone THERMOTRONIC	69B
U12	Valid for left-hand drive vehicles	13J
U12	Valid for left-hand drive vehicles	53J
U123	Valid for taxi electrical system	69B
U13	Valid for right-hand drive vehicles	13J
U230	Valid for electric power steering	58K
U255	Valid for front fog lamps	66B
U40	Valid for countries with daytime running lights	79B
U43	Valid for ECE	72B
U52	Valid for Japan	4G
U54	Valid for all except Japan	26H
U631	Valid for COMAND	26B
U865	Valid for Audio 20	22B
U866	Valid for Audio 50	22B
U838	Valid for ESP Basic	1G
U939	Valid for ESP Premium	1G
U940	Valid without DIRECT SELECT	18B
W15/2	Left footwell ground point	59L
W15/5	Left front footwell ground point	14L

Code:	Designation:	Position:
W15/7	Right front footwell ground point	14L
W18	Left front seat crossmember ground point	59L
W2	Right front ground point at lamp unit	706
W2	Right front ground point at lamp unit	746
W2	Right front ground point at lamp unit	786
W2	Right front ground point at lamp unit	826
W9	Left front ground point (at lamp unit)	736
W9	Left front ground point (at lamp unit)	776
W9	Left front ground point (at lamp unit)	806
X11/4	Diagnostic connector	39L
X18	Vehicle interior and harness for tail lamp electrical connector	42J
X190	Instrument panel and electric steering lock electrical connector	16H
X29/1	Glove compartment electrical connector	11H
X30/26	Vehicle floor chassis CAN 2 (CAN E2) potential distributor electrical connector	63L
X30/30	Vehicle floor chassis CAN voltage distributor electrical connector	62L
X30/30	Vehicle floor chassis CAN voltage distributor electrical connector	62L
X35/4	Front passenger seat connector block	5J
X35/4	Front passenger seat connector block	7J
Z6/56	Circuit 31 connector sleeve	72H
Z6/56	Circuit 31 connector sleeve	76H
Z6/56	Circuit 31 connector sleeve	80H
Z6/97	Right lamp unit circuit 31 connector sleeve	70H
Z6/97	Right lamp unit circuit 31 connector sleeve	74H
Z6/97	Right lamp unit circuit 31 connector sleeve	78H
Z6/97	Right lamp unit circuit 31 connector sleeve	82H
Z68/1	Right lamp unit circuit 31 connector sleeve	81H
Z68/11	Instrument panel circuit 31 climate control LIN connector sleeve	41H
Z6z4	Rear air conditioning LIN bus ground line connector sleeve	45H
Z7/21	Circuit 31 connector sleeve	146
Z7/21	Air conditioning circuit 30 connector sleeve	48H
Z7/21	Air conditioning circuit 30 connector sleeve	54H

