

Document number : pe54.15-p-2108-97daa
Document title : Wiring diagram for fuse box (F1/1)

Code :	Designation :	Position :
A0	Color code key	15L
F1/1	Fuse box	4A
F1/f1f1	Prefuse 1	5A
6t/7	Additional battery	2L
N10/1	Front SAM control unit with fuse and relay module	7L
N73	Electronic ignition switch control unit	11L
U12	Valid for left-hand drive vehicles	4G
U13	Valid for right-hand drive vehicles	4H
U490	Valid for 7-speed automatic transmission	5G
W15/5	Left front footwell ground point	4K
W15/7	Right front footwell ground point	4L
Z6z1	Circuit 31 connector sleeve	3G

