


Code:	Designation:	Position:
A0	Color code key	104L
Code 4U7	Start/stop voltage dip protection	26
Code 4U7	Start/stop voltage dip protection	8H
Code 580	Air conditioning	696
Code 581	Automatic air conditioning	696
Code 924	Bivalent natural gas drive	84K
Code 803	EEO start/stop function	26
Code B03	EEO start/stop function	8H
Code ME04	Hybrid drive 20 kW VARIANT	26
Code ME04	Hybrid drive 20 kW VARIANT	8H
Code U42	BlueTEC diesel exhaust treatment	84K
F32	Front electrical prefuse box	6L
F32	Front electrical prefuse box	12L
F32F151	Prefuse 151	10K
F32F154	Prefuse 154	3K
F32F154	Prefuse 154	10K
F32F156	Prefuse 156	4K
F32F157	Prefuse 157	3K
F32F162	Prefuse 162	10K
M4/7	Combustion engine and air conditioning with integrated control fan motor	5K
		16L
N10/1	Front SAM control unit with fuse and relay module	5A
N10/1	Front SAM control unit with fuse and relay module	20A
N10/1	Front SAM control unit with fuse and relay module	28A
N10/1	Front SAM control unit with fuse and relay module	36A
N10/1	Front SAM control unit with fuse and relay module	44A
N10/1	Front SAM control unit with fuse and relay module	52A
N10/1	Front SAM control unit with fuse and relay module	60A
N10/1	Front SAM control unit with fuse and relay module	85A
N10/1	Front SAM control unit with fuse and relay module	92A
N10/1	Front SAM control unit with fuse and relay module	79A
N10/1	Front SAM control unit with fuse and relay module	69A
N10/1	Front SAM control unit with fuse and relay module	11A
N10/1f15	Fuse 15	75A
N10/1f22	Fuse 22	16A
N10/1f24	Fuse 24	83A
N10/1f8	Fuse 8	77A
N10/1AN	Engine circuit 87 relay	15A
N118/2	CMG control unit	85L
N2/10	Supplemental restraint system control unit	76L

Code:	Designation:	Position:
N3/10	ME-SFI [ME] control unit	33L
N3/10	ME-SFI [ME] control unit	55L
N3/10	ME-SFI [ME] control unit	51L
N3/10	ME-SFI [ME] control unit	59L
N3/9	ME-SFI [ME] control unit	80L
N3/9	CDI control unit	38L
N3/9	CDI control unit	63L
N3/9	CDI control unit	85L
N3/9	CDI control unit	67L
U1018	Valid for gasoline engine 276	24J
U1018	Valid for gasoline engine 276	476
U1018	Valid for gasoline engine 276	536
U1018	Valid for gasoline engine 276	946
U1027	Valid for gasoline engine 271 continuous fuel injection system (electronic)	24J
U1027	Valid for gasoline engine 271 continuous fuel injection system (electronic)	316
U1027	Valid for gasoline engine 271 continuous fuel injection system (electronic)	426
U1027	Valid for gasoline engine 271 continuous fuel injection system (electronic)	576
U1027	Valid for gasoline engine 271 continuous fuel injection system (electronic)	986
U1032	Valid for engine 278 and 157	24J
U1032	Valid for engine 278 and 157	476
U1032	Valid for engine 278 and 157	536
U1032	Valid for engine 278 and 157	946
U1032	Valid for engine 278 and 157	79J
U1073	Valid for model 212, 095	79J
U127	Valid for gasoline engine 276, 9	79J
U127	Valid for combustion engines 272 and 273 KE	446
U127	Valid for combustion engines 272 and 273 KE	576
U127	Valid for combustion engines 272 and 273 KE	906
U127	Valid for combustion engines 272 and 273 KE	79K
U152	Valid for combustion engines 156	21J
U152	Valid for gasoline engine 156	416
U152	Valid for gasoline engine 156	576
U152	Valid for gasoline engine 156	926
U157	Valid for gasoline engine 156	79L
U157	Valid for combustion engine 272 DE	426
U157	Valid for combustion engine 272 DE	886
U221	Valid for combustion engine 272 DE	79J
U240	Valid for China	316
	Valid for all except ECO start/stop function	2F

Code:	Destination:	Position:
U240	Valid for all except ECO start/stop function	86
U242	Valid for fan motor 800 W	86
U243	Valid for diesel engine 651 with all-wheel drive	18J
U243	Valid for diesel engine 651 with all-wheel drive	366
U243	Valid for diesel engine 651 with all-wheel drive	83J
U244	Valid for BlueTEC	28J
U244	Valid for BlueTEC	28J
U244	Valid for BlueTEC	666
U244	Valid for BlueTEC	666
U249	Valid for diesel engine 651 without all-wheel drive	366
U249	Valid for diesel engine 651 without all-wheel drive	83J
U249	Valid for diesel engine 651 without all-wheel drive	456
U362	Valid for gasoline engine 274	886
U362	Valid for gasoline engine 274	79K
U362	Valid for gasoline engine 274	83K
U391	Valid for gasoline engine 276, 8	79K
U391	Valid for gasoline engine 276, 8	28J
U561	Valid for Delphi system	28J
U561	Valid for Delphi system	676
U562	Valid for Bosch system	28J
U562	Valid for Bosch system	676
U739	Valid for gasoline engine 271 DE	21J
U739	Valid for gasoline engine 271 DE	316
U739	Valid for gasoline engine 271 DE	436
U739	Valid for gasoline engine 271 DE	466
U739	Valid for gasoline engine 271 DE	966
U819	Valid for gasoline engine 272	79H
U819	Valid for gasoline engine 272	21J
U819	Valid for gasoline engine 272	496
U880	Valid for diesel engine 642	18J
U880	Valid for diesel engine 642	476
U880	Valid for diesel engine 642	616
U880	Valid for diesel engine 642	956
U880	Valid for diesel engine 642	83H
U948	Valid for diesel engine 651	18J
U948	Valid for diesel engine 651	366
U948	Valid for diesel engine 651	466
U948	Valid for diesel engine 651	616
U948	Valid for diesel engine 651	936

Code:	Designation:	Position:
U948	Valid for diesel engine 651	83J
U948	Valid for diesel engine 651	83K
U948	Valid for diesel engine 651	27J
U948	Valid for diesel engine 651	27J
U948	Valid for diesel engine 651	27J
U948	Valid for diesel engine 651	656
U948	Valid for diesel engine 651	656
U950	Valid for fan motor 650 W	8F
U968	Valid for fan motor 650 W	8F
U968	Valid for mild hybrid drive	626
U968	Valid for mild hybrid drive	726
U968	Valid for mild hybrid drive	83J
U977	Valid for mild hybrid drive	626
U977	Valid for mild hybrid drive	15H
W2	Left front ground point (at lamp unit)	15H
W2	Right front ground point (at lamp unit)	156
W2	Left front ground point (at lamp unit)	16H
X25/2	Engine compartment/interior electrical connector	16H
X25/2	Engine compartment/interior electrical connector	70H
X26	Interior and engine wiring harness electrical connector	43H
X26	Interior and engine wiring harness electrical connector	42H
X26	Interior and engine wiring harness electrical connector	45H
X26	Interior and engine wiring harness electrical connector	46J
X26	Interior and engine wiring harness electrical connector	48H
X26	Interior and engine wiring harness electrical connector	73J
X26	Interior and engine wiring harness electrical connector	98H
X26	Interior and engine wiring harness electrical connector	92H
X26	Interior and engine wiring harness electrical connector	89H
X26	Interior and engine wiring harness electrical connector	90H
X26	Interior and engine wiring harness electrical connector	93H
X26	Interior and engine wiring harness electrical connector	95H
X26	Interior and engine wiring harness electrical connector	97H
Y19/3	Evaporator shut-off valve	73L
Y84	Radiator shutter's actuator	35L
Y84	Radiator shutter's actuator	40L
Z7/35z1	Circuit 87 M1e connector sleeve	42L
Z7/35z1	Circuit 87 M1e connector sleeve	40H
Z7/35z1	Circuit 87 M1e connector sleeve	91L
Z7/35z1	Circuit 87 M1e connector sleeve	89L
Z7/35z2	Circuit 87 M1e connector sleeve	89L
Z7/35z2	Circuit 87 M2e connector sleeve	97L
Z7/36	Circuit 87 M2e connector sleeve	44L
Z7/36z1	Circuit 87 M2e connector sleeve	46L

Code:	Designation:	Position:
Z7/36z1	Circuit 87 M2e connector sleeve	48L
Z7/36z2	Circuit 87 M2e connector sleeve	45L
Z7/5z1	Circuit 87 connector sleeve	95L
Z7/5z2	Circuit 87 connector sleeve	48L
Z7/5z2	Circuit 87 connector sleeve	48L
Z7/5z2	Circuit 87 connector sleeve	95L
Z7/5z3	Circuit 87 connector sleeve	94L
Z7/5z3	Circuit 87 connector sleeve	95K
Z7/98z3	Circuit 87 M2e connector sleeve	92L



Cut here