

Model 205 with transmission 722, 724, 725
 Model 213 with transmission 725
 Model 253 with transmission 724, 725



P68.20-4707-09

Shown on model 205 with code 581 (automatic air conditioning)

- | | | | |
|---|----------------------|-------|----------------------------------|
| 1 | Center console cover | 6 | Electrical connector |
| 2 | Stowage box cover | 7 | Electrical connector |
| 3 | Bolts | 8 | Electrical connectors |
| 4 | Electrical connector | N58/1 | Climate control operating unit |
| 5 | Electrical connector | N72/1 | Upper control panel control unit |

	Information on preventing damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
	Remove/install		
1	Switch off ignition and store transmitter key outside of transmission range (min. 2 m)		
2	Remove stowage box cover (2)	Model 205 with transmission 722, 724, 725 Model 253 with transmission 724, 725 Model 213 with transmission 725	AR68.20-P-1020LW AR68.20-P-1020LWE
3	Unscrew bolts (3) from center console cover (1)		
4	Lift center console cover (1) at rear and move out of instrument panel at top front until electrical connectors (4, 5) are accessible		Cover center console and instrument panel with a cloth. Otherwise, the center console and instrument panel can be damaged.
5	Disconnect electrical connector (4) from air conditioning operating unit (N58/1)	Model 205 with transmission 722, 724, 725 with code 581 (Automatic air conditioning) Model 213 with transmission 725 with code 581 (Automatic air conditioning) Model 253 with transmission 724, 725 with code 581 (Automatic air conditioning)	
6	Disconnect electrical connector (5) at upper control panel control unit (N72/1)		
7	Disconnect electrical connectors (6, 7, 8)		The number can vary according to the equipment.
8	Remove cover on center console (1)		

9	Install in the reverse order		
---	------------------------------	--	--