Models 164, X164 and 251 (M-Class, GL-Class, and R-Class)





Reset Service Indicator

- 1. Insert key into ignition, switch to position "1".
- 2. Press buttons or repeatedly until the mileage is displayed within the Multifunction display.
- 3. Press cluster illumination button (1) 3 times in short succession. The battery voltage will be displayed
- 4. Press the up 4 / 5 buttons until the service menu appears.
- 5. Use the and buttons to select menu option "Confirm".
- 6. Press button until "Complete Service" is selected.
- 7. Confirm "Complete Service" with button . The display will show "Service Confirmed".

Feedback welcome on startekinfo.team@mbusa.com.