
Model	166.0
	as of model year 2016
	with code 4U7 (Start/stop voltage dip protector)
	except code ME05 (HYBRID DRIVE 80KW VARIANT (INCLUDING PLUGIN))
Model	292
	with code 4U7 (Start/stop voltage dip protector)



P54.10-4422-09

1 Additional battery

2 Ground line electrical connection

3 Positive line electrical connection

4 Catch lug

⚠ Danger !	Risk of explosion from explosive gas. Risk of poisoning and caustic burns from swallowing battery electrolyte. Risk of injury through burns to skin and eyes from battery acid or when handling damaged lead-acid batteries	No fires, sparks, open flames or smoking. Wear acid-resistant gloves, clothing and glasses. Only pour battery acid into suitable and appropriately marked containers.	AS54.10-Z-0001-01A
	Information on preventing damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
	Notes on battery		AH54.10-P-0001-01A
i	Notes on AGM battery		AH54.10-P-0002-01A
XX	Remove/install		
1	Remove left rear seat cushion	Model 166.0 as of model year 2016 with code 4U7 (Start/stop voltage dip protector) except code ME05 (HYBRID DRIVE 80KW VARIANT (INCLUDING PLUGIN))	AR91.12-P-1020GQ
		Model 292 with code 4U7 (Start/stop voltage dip protector)	AR91.12-P-1021GQC
2	Remove folding rear backrest at left	Model 166.0 as of model year 2016 with code 4U7 (Start/stop voltage dip protector) except code ME05 (HYBRID DRIVE 80KW VARIANT (INCLUDING PLUGIN)) Model 292	AR91.12-P-1620GQ AR91.12-P-1721GQC
		with code 4U7 (Start/stop voltage dip protector)	AN91.12-1-17210Q0
3	Remove left rear door sill molding		AR68.30-P-4100GQ
4	Pull floor covering out of trunk lining at left side and fold forward	() Carefully pull floor covering out of trunk lining at left lower side. Otherwise, the floor covering may be damaged.	
5	Detach ground line electrical connection (2) from additional battery (1)		
6	Detach positive line electrical connection (3) from additional battery (1)		
7	Push catch tabs (4) outward and pull out additional battery (1)		

© Daimler AG, 12/23/22, L/01/17, ar54.10-p-0121gqb, Remove/install park pawl battery Model 166.0 as of model year 2016 with code 4U7 (Start/stop voltage dip protector) except code ME05 (HYBRID DRIVE 80KW VARIANT (INCLUDING PLUGIN)) Model 292 with code 4U7 (Start/stop voltage dip protector)

8	Install in the reverse order		
---	------------------------------	--	--