



Pry off the shifter cover with trim removal tool. You need to put some force to pry off.



Pull out the walnut cover. There are two clips close to the front (red circle on above picture).



Remove the screw that holds the control unit.