


AR68.10-P-1150GH

Removing and installing center air nozzle

4.2.97

## MODEL 163


1 Center air nozzle  
Arrows Catch



P68.10-0514-05

☒ ☒	Remove/install		
1	Pry center air nozzle (1) at bottom out of catch (arrows)	<b>i</b> <b>Installation:</b> air nozzle should catch audibly.	
		<b>⚠</b> Long wedge	<a href="#">115 589 03 59 00</a>
2	Pry center air nozzle (1) at top out of catch (arrows)	<b>i</b> <b>Installation:</b> air nozzle should catch audibly.	
		<b>⚠</b> Long wedge	<a href="#">115 589 03 59 00</a>
3	Pull center air nozzle (1) out of air duct		

4	Install in the reverse order		
---	------------------------------	--	--



115 589 03 59 00

Long wedge