

## Maintenance: Service Intervals

### A - Service Schedule

#### A - Service Schedule

##### Vehicle Passenger Compartment

###### Function Check:

- Check Tele Aid by pressing SOS button to make test call to Response Center.
- Horn, headlamp flasher, hazard flasher, turn signals.
- Warning/indicator lamps, illumination and interior lighting.
- Exterior lighting incl. headlamps.
- Windshield wipers, rear window wiper, windshield/rear window washer.
- Headlamp cleaning system.
- Reset Flexible Service System (FSS) counter in instrument cluster.

##### Wheels, Brakes

- Check brake pads for lining thickness (1 front wheel only).
- Check tires for damage and condition.
- Correct tire inflation pressure.

##### Engine Compartment

- Engine oil and filter change.
- Check and correct fluid level:
  - Engine cooling system, antifreeze and corrosion protection.
  - Brake system.
  - Windshield washer system.
- If so equipped: Battery, wet cell; Check acid level, replenish.
- Check battery condition using "Midtronics MCR 717" Tester.
- Lubricate catch, safety catch and hinges on engine hood.