
GF47.20-P-4100-01GH	Fuel filter with integrated fuel pressure	Model 163	⊯ GF
	regulator position		

The fuel filter with integrated fuel pressure regulator is positioned at the top of the fuel tank next to the fuel delivery module.

55/1 Fuel filter with integrated fuel pressure regulator



P47.20-0285-11