
AR72.29-P-0001GH

Removing and installing center console switch group

14.2.97

MODEL 163.154 /172 /174 up to 31.8.01

S21 Center console switch group



P72.29-0273-05

X	Removal, installation		
1	Remove ashtray at front of center console		<u>AR68.20-P-2400GH</u>
2	Unclip center console switch group (S21)	i Center console switch group can only be replaced completely.	
3	Install in the reverse order		