


AR27.19-P-0200-01A	Installing selector valve in driver of detent plate		
--------------------	---	--	--

 When installing the electrohydraulic control module in the transmission housing, the plastic part of the selector valve (10) must engage in the driver of the detent plate (11).

