

Item	Designation	Coordi
<u>F1</u>	Fuse and relay module	4B 16B 23B 30B
<u>F1f42</u>	Fuse 42	5C
<u>F1k15</u>	Central locking, tailgate unlocking relay	30C
<u>F1k20</u>	Central locking, all doors lock relay	6C
<u>F1k23</u>	Central locking, right front door and rear doors unlock relay	20C
<u>F1k24</u>	Central locking, left front door and fuel filler flap unlock relay	12C
<u>G1</u>	Battery	10F
<u>M14/10</u>	Fuel filler flap CL motor	16L
<u>M14/5</u>	Right front door CL motor	8L
<u>M14/5s1</u>	CL microswitch	7L
<u>M14/6</u>	Driver door CL motor	3L
<u>M14/7</u>	Tailgate CL motor	31L
<u>M14/8</u>	Left rear door CL motor	20L
<u>M14/9</u>	Right rear door CL motor	27L
<u>M14/9s1</u>	CL microswitch	26L
<u>N10</u>	All-activity module	2A 13A 26A 36A
<u>N72</u>	Lower control field control module	37L
<u>N72s23</u>	Central locking switch	37K
<u>S87/3</u>	Right rear door rotary tumbler microswitch	25L
<u>S87/6</u>	Right front door rotary tumbler microswitch	6L
<u>S88/1</u>	Tailgate rotary tumbler switch	33L
<u>W16/4</u>	Ground (output ground - component compartment - right)	11G
<u>W18</u>	Ground (left front seat crossmember)	19F
<u>W19</u>	Ground (right front seat crossmember)	26F
<u>W29/2</u>	Ground (right A-pillar)	2E 6E
<u>W8</u>	Tailgate ground	30G
<u>X12/12</u>	Circuit 30 terminal block at relay module 1	8E
<u>X12/13</u>	Circuit 15 terminal block at relay module 1	9E
<u>X12/14</u>	Circuit 31 terminal block at relay module 1	10E
<u>X18</u>	Interior and taillamp harness connector, cockpit	12G
<u>X18/1</u>	Interior/tailgate connector	29G
<u>X35/1</u>	Left front door separation point	1H
<u>X35/2</u>	Right front door separation point	5H
<u>X35/3</u>	Left rear door separation point	18H
<u>X35/4</u>	Right rear door separation point	25H
<u>X4/37</u>	Terminal block (circuit 30)	8F
<u>Z51/8</u>	Interior connector sleeve II (circuit 31, right front)	2F 6F

<u>Z51/9</u>	Interior connector sleeve III (circuit 31, left front seat)	19G
<u>Z52/1</u>	Interior connector sleeve IV (circuit 31, right front seat)	26G
<u>Z53/1</u>	Interior connector sleeve (central locking motor 1)	20F
<u>Z53/2</u>	Interior connector sleeve (central locking motor 2)	21F
<u>Z53/7</u>	Interior connector sleeve (central locking motor 3)	13I
<u>Z55/1</u>	Tailgate connector sleeve (circuit 31)	30H
<u>Z59/3</u>	Front door connector sleeve (circuit 31)	2I 6I
<u>Z59/4</u>	Rear door connector sleeve (circuit 31)	19I 26I