


Socket assignment on All-Activity Module (AAM) (N10)

SV1 Connector to fuse and relay module
 SV2 Connector, left of engine compartment
 SV3 Connector, interior
 SV4 Connector, cockpit
 SV5 Connector, roof
 SV6 Connector, radio antenna
 F1 Fuse and relay module
 N10 All-Activity Module (AAM)



P54.21-0247-12