



GF54.15-P-1255-18GH	Fuse and relay box, relay assignment to relay holder		 GF
---------------------	--	--	--

F1 to F48 Fuses
k1 to k31 Relay



P54.15-0438-06

Bay	Designation	Designation
k1		Heated rear window relay
k2		Two-tone signaling system relay
k3		Fuel pump relay
k4		Left turn signal lamp relay
k5		Circuit 58 relay
k6		ESP stop lamp suppression relay

k7		Right turn signal lamps relay
k8		Starter relay
k9		Circuit 58R relay
k10		Relay not assigned
k11		Diesel voltage supply relay
k12		Circuit 15 relay
k13		Circuit 58L relay
k14		Convenience relay
k15		Central locking relay, unlock rear-end door
k16		Right front power window relay

Bay	Designation	Designation
k17		Front wiper motor relay
k18		Left front power window relay
k19		Circulating pump relay
k20		Central locking relay, lock all doors
k21		Blower motor relay
k22		Low beam headlamp relay
k23		Central locking relay, unlock right front door and rear doors
k24		Central locking relay, unlock left front door and fuel filler flap
k25		High pressure/return pump relay
k26		Engine fan stage 1 relay
k27		Spare
k28		Air pump relay
k29		Rear fog lamp relay
k30		Fog lamp relay
k31		Alarm horn signal relay