

Item	Designation	Coordin
<u>F32</u>	Front prefuse	4A 11A
<u>F32f4</u>	Fuse 4	5B
<u>F32f5</u>	Fuse 5	4B
<u>F32f6</u>	Fuse 6	7B
<u>F32f7</u>	Fuse 7	9B
<u>F32f8</u>	Fuse 8	11B
<u>F58</u>	Engine compartment fuse and relay box	12L
<u>G1</u>	Battery	2L
<u>G2</u>	Generator	4L
<u>M4/7</u>	Electric suction fan engine and AC with integrated control	9L
<u>N47-5</u>	ESP control module	7L
<u>U74</u>	Valid for diesel vehicles	3D
<u>U75</u>	Valid for gasoline engines	1D
<u>W10</u>	Ground (battery)	1G