

## MODEL 164


## roof antenna module

Shown on model 164.1

1 Screws

A2/93 Roof antenna module

A2/93a2 Antenna amplifier



P82.62-2768-06

☒ ☒	Remove/install		
⚠	Notes on avoiding damage to electronic components due to electrostatic discharge		AH54.00-P-0001-01A
1	Remove headliner		AR68.30-P-4300GZ
2	Remove roof antenna module (A2/93)		AR82.62-P-8979GZ
3	Remove bolts (1)		
4	Release antenna amplifier module (A2/93a2) toward side (arrow A) and remove upward (arrow B).	ⓘ Do not damage or contaminate printed circuit board.	
5	Install in the reverse order		