


X11/22	Data link connector
1	Electronic ignition/starter switch control module (model 168)
2	-
3	TNA signal (gasoline)
3	TD signal (diesel)
4	Circuit 31 (ground) BRN W15/2 up to 8/2006
5	Circuit 31 (electronics ground) BRN W15/2 as of 9/2006
6	CAN interior bus (H)
7	ME Motor electronics (ME-SFI)
8	Circuit 87 voltage BLK/BLUE cir.15 Fuse 56 in F4
9	ABS Anti-lock brake system (model 168)
9	ETS Electronic traction system (model 163)
9	ASR Acceleration slip regulation (model 168)



P07.00-0323-10

9	ESP Electronic Stability Program	12	RD Radio Audio 10, Audio 30, and Audio 30 APS with D2B (model 168)
10	-	13	AB Airbag/emergency tensioning retractor
11	ETC Electronic transmission control	14	CAN interior bus (L)
11	FTC Front transmission control (model 168)	15	IC Instrument cluster
11	Automatic clutch (model 168)	16	Circuit 30 voltage 30 RED cir.30 Fuse 58 in F4
12	AAM All activity module		