



P20.40-2124-09

Shown on engine 272

- 1 Engine intake air duct
- 2 Electrical connector

- 3 Fan shroud
- 4 Bolts

- 5 Radiator

Modification notes

17.10.05	Disconnect ground line from battery - removed		
----------	-----------------------------------------------	--	--

Icons	Remove/install		
⚠	Notes on self-locking nuts and bolts		AH00.00-N-0001-01A
1	Remove left and right engine intake air duct (1)		
2	Remove upper radiator crossmember	Engine 273	AR62.30-P-2300GZ
3	Unplug electrical connection (2) on fan shroud (3)		
4	Unscrew bolts (4) at fan shroud (3)		
5	Remove fan shroud (3) from lower mounts (5) on radiator	<b>i</b> When removing fan shroud (3) observe that none of attached lines are damaged on radiator (5).	
6	Install in the reverse order		
7	Connect STAR DIAGNOSIS and read fault memory	<b>i</b> Stored faults which may be caused by disconnecting cables or by simulation during test operations, must be erased in the fault memory after completing the work.	