


1 Install poly-V belt according to running diagram.

- 1 *Belt pulley/vibration damper*
- 2 *Belt pulley on refrigerant compressor*
- 3 *Power steering pump belt pulley*
- 4 *Pulley*
- 5 *Alternator belt pulley*
- 6 *Coolant pump belt pulley*
- 7 *Tensioner pulley*



P13.20-2033-06