
## MODEL 164 with CODE (580) Automatic air conditioning

- 1 2 3, 4 Air filter housing Cover
- Dust filter



P83.00-2161-05

XX	Remove/install		
1 F <b>S</b> AR	Remove glove compartment Remove/install glove box		AR68.10-P-1400GZ
2	Unlock cover (2) on dust filter housing (1) in direction of the arrow and remove		
3	Remove dust filters (3, 4)	i Installation: Replace dust filters (3, 4), do not clean. i Installation: Observe the installation position (arrows) printed on the dust filters (3, 4).	
4	Install in the reverse order		