

Panel in left rear fender liner
Electrical connector

Nuts

3

6

A2/46 Left rear TPM [RDK] wheel antenna



4 Panel in right rear fender liner5 Nuts

Electrical connector

A2/47 Right rear TPM [RDK] wheel antenna

XX	Remove/install		
1	Fold down panel in left rear fender liner (1) or panel in right rear fender liner (4)	i Fold down panel in left rear fender liner (1) or panel in right rear fender liner (4) far enough so that the right rear TPM [RDK] wheel antenna (A2/47) or left rear TPM [RDK] wheel antenna (A/46) is accessible, see: ↓	
		Remove/install fender liner in rear fender	AR88.10-P-1400GZ
2	Disconnect electrical connector (2) or electrical connector (6)		
3	Unscrew nuts (3) or nuts (5) and remove left rear TPM [RDK] wheel antenna (A2/46) or right rear TPM [RDK] wheel antenna (A2/47)		
4	Install in the reverse order		
5	Read out fault memory and erase	i Stored faults which may be caused by assembly work, test work, removed lines or a simulation, must be processed and erased in fault memories after completing the work.	
A D			AD00.00-P-2000-04A

P40.15-2309-07