



P83.25-2244-07

- 1 Rubber seal
2 Rubber seal
3 Water repellent

- 4 Clip
5 Cover

☒☒☒	Remove/install		
	Risk of injury in the form of trapping or crushing, or even severing of limbs, if caught in windshield wiper mechanism	Always remove ignition key when working on windshield wiper mechanism.	AS82.30-Z-0001-01A
1	Remove wiper arms		AR82.30-P-6100GZ
2	Detach rubber seal (1) from cover (5)		
3	Detach rubber seal (2) from left and right fender		
4	Unclip washer fluid hose from clip (4)		
5	Remove cover (5)	<p>i Detach cover (5) on one side in the opposite direction.</p> <p>i Installation: Lubricate upper edge of cover (5) and windshield at bottom with soapy water.</p>	
6	Install in the reverse order		