


Relay assignment ^{as of} before production period 31.05.2006 to 2008

20 to 72 Fuses
 K to P Relays
 R to T Relays

F4 Load compartment fuse and relay box

The load compartment fuse and relay box is installed in the load compartment on the right of the wheelhouse.




P54.15-2729-03

Relay assignment as of production period 01.06.2006

20 to 72 Fuses
 K to P Relays
 R to V Relays

F4 Load compartment fuse and relay box

The load compartment fuse and relay box is installed in the load compartment on the right of the wheelhouse.



P54.15-2966-03

Relays	Designation
K	Before production period 31.05.2006 ● Terminal 15R power outlet relay, with power-down As of production period 01.06.2006 ● Circuit 15R seat adjustment
L	Valid for code 550 Trailer hitch: Terminal 30X
M	Heated rear window relay
N	Circuit 15 relay / terminal 87FW
O	Fuel pump relay
P	Rear wiper relay
R	Circuit R relay115R
S	-

T	As of production period 01.06.2006 <ul style="list-style-type: none">● Circuit 30, socket for 2nd seat row and load compartment
U	As of production period 01.06.2006 <ul style="list-style-type: none">● Circuit 30, trailer
V	As of production period 01.06.2006 -