


F58 Engine compartment fuse and relay box



P54.15-2728-03

| Relays | Designation |
|--------|---|
| A | ● Wiper level relay 1/2 (F58kA) |
| B | ● Wiper ON/OFF relay (F58kB) |
| C | ● Coolant circulation pump relay (F58kC) |
| D | ● Engine circuit 87 relay (F58kD) |
| E | Valid for engine 156, 272, 273: ● Air pump relay (F58kE) |
| F | ● Fanfare horn relay (F58kF) |
| G | Valid for model 164.1 with code (489) Airmatic (air suspension with level adjustment and adaptive dampening-system ADS), Model 164.8: ● Air spring compressor relay (F58kG) |
| H | ● Circuit 15 relay (F58kH) |
| I | ● Starter relay (F58kI) |