

Your Vehicle: 2011 Mercedes Benz Truck R 350 4MATIC (251.165) V6-3.5L (272.967)




**SAVE \$25**  
instantly on 4 tires!



[Vehicle](#) » [Lighting and Horns](#) » [Diagrams](#) » [Function Diagrams](#) » [PE82.10-U-2058RAA Electrical Function Diagram For Backup Light Actuation](#)

PE82.10-U-2058RAA Electrical Function Diagram For Backup Light Actuation

**PE82.10-U-2058RAA Electrical Function Diagram For Backup Light Actuation**  
- as of model year 09



Item	Designation	Coordinates
<u>A8/1</u>	Transmitter key	5B
<u>A80</u>	Intelligent servo module for DIRECT SELECT	2G
<u>E3e3</u>	Left backup lamp	9J
<u>E4e3</u>	Right backup lamp	13J
<u>N10/8</u>	Rear SAM control module	7D
<u>N73</u>	EIS [EZS] control unit	4A
<u>N93</u>	Central gateway control module	2D
<u>CAN B</u>	Interior CAN	4E 6B
<u>CAN C</u>	Engine compartment CAN	2F
1	Circuit 15, status	7C
2	Reverse gear, status	3F 5D
3	Backup lamp, actuation	9J 14J

**Component Locations:** Component Location photographs can be found via their component names at the vehicle level. [See: Locations\Components](#)

[Account](#) | [Vehicle](#) | [Help](#) | [Contact](#) | [AutoZone Community](#) | [Exit](#)

© 2018 ALLDATA, LLC. All Rights Reserved. [Trademarks](#) | [Privacy Policy](#) | [Terms and Conditions](#)