
18	.09	.20	19
----	-----	-----	----

Model	217, 222
	up to model year 2018
	with code 233 (Adaptive cruise control Plus (DISTRONIC PLUS))
Model	217, 222
	up to model year 2018
	with code 237 (Active Blind Spot Assist)
Model	217, 222
	up to model year 2018
	with code 238 (Active lane keeping Assist)
Model	217, 222
	up to model year 2018
	with code 258 (Collision warning system with active brake application FCW-Stop)
Model	217, 222
	up to model year 2018
	with code 266 (DISTRONIC PLUS with Cross-Traffic Assist (DTR+Q))
Model	217, 222
	up to model year 2018
	with code 268 (Brake Assist System Plus)
Model	217, 222
	up to model year 2018
	with code 269 (Brake Assist PLUS with Cross-Traffic Assist (BAS+Q)
Model	217, 222
	up to model year 2018
	with code 271 (Autonomous brake intervention/pedestrian protection)
Model	217, 222
	up to model year 2018
	with code 300 (PRE-SAFE® Brake)

Shown on model 222

1	Electrical connector
A90	COLLISION PREVENTION
	ASSIST controller unit
B29/2	Left front bumper radar sensor
B29/3	Right front bumper radar sensor



P30.30-2530-06

	Notes on preventing damage to electronic components due to a magnetic tool		AH54.00-P-0002-01A
	Information on preventing damage to electronic components due to electrostatic		AH54.00-P-0001-01A
	discharge		
XX	Remove/install		
1	Perform commissioning of COLLISION PREVENTION ASSIST controller unit (A90), front left bumper radar sensor (B29/2) or front right bumper radar sensor (B29/3)	When replacing COLLISION PREVENTION ASSIST controller unit (A90), front left bumper radar sensor (B29/2) or front right bumper radar sensor (B29/3).	
₩AD			AD00.00-P-2000-04B

© Mercedes-Benz AG, 7/13/21, X/07/21, ar30.30-p-1210lf, Remove/install radar sensor Page 1 of 2 Model 217, 222 up to model year 2018 with code 233 (Adaptive cruise control Plus (DISTRONIC PLUS)) Model 217, 222 up to model year 2018 with code 237 (Active Blind Spot Assist) Model ...

2	Remove impact absorber	Model 217 up to model year 2018	AR88.20-P-2050LC
		Model 222 up to model year 2018	AR88.20-P-2050LF
3.1	Detach electrical connection (1) from left front outer bumper radar sensor (B29/2) or right front outer bumper radar sensor (B29/3)	Model 217, 222 up to model year 2018 except code 258 (COLLISION PREVENTION ASSIST)	
3.2	Disconnect electrical connection (1) on COLLISION PREVENTION ASSIST controller unit (A90)	Model 217, 222 up to model year 2018 with code 258 (COLLISION PREVENTION ASSIST)	
4.1	Unlock retaining lugs (arrows) and bumper radar sensor at the front left (B29/2), or bumper radar sensor at the front right (B29/3)	Model 217, 222 up to model year 2018 except code 258 (COLLISION PREVENTION ASSIST)	
4.2	Unlock retaining lugs (arrows) and remove COLLISION PREVENTION ASSIST controller unit (A90)	Model 217, 222 up to model year 2018 with code 258 (COLLISION PREVENTION ASSIST)	
5	Install in the reverse order		