


Mode	MD mode	Mod. des. overview	S-SEDAN LONG WHEELBASE USA
FIN/MD	WDB 2201701A187200	Catalog	07N
VIN	WDBNG70J11A187200	Major assembly	M - Engine
Sales designation	S 430	Major assembly MD	113941 30 262745
Assortment class	Car	Group	54 - ENGINE CABLE HARNESSES
Market	North America	Subgroup	222 - ENGINE CABLE HARNESS S/CL-CLASS
Picture number	B54222000002.030228		




- Parts list -

Mode	MD mode	Mod. des. overview	S-SEDAN LONG WHEELBASE USA
FIN/MD	WDB 2201701A187200	Catalog	07N
VIN	WDBNG70J11A187200	Major assembly	M - Engine
Sales designation	S 430	Major assembly MD	113941 30 262745
Assortment class	Car	Group	54 - ENGINE CABLE HARNESES
Market	North America	Subgroup	222 - ENGINE CABLE HARNESS S/CL-CLASS

Item no.	Part number	Designation/description	Quantity	Version
5	A 220 540 45 05	CABLE HARNESS ENGINE CABLE HARNESS,S-CLASS Code: 494/498 [031] Up to engine: 30 107367	001	
5	A 220 540 74 05	CABLE HARNESS ENGINE CABLE HARNESS,S-CLASS Code: 494/498 [801, 032] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001	
14	A 220 540 71 06	CABLE HARNESS ENGINE CABLE HARNESS,S-CLASS [810, 811] FROM MODEL YEAR 2001 - CODE 801	001	
14	A 220 540 92 32	ELECTRIC CABLE ENGINE CABLE HARNESS,S-CLASS Code: - 479 [820] FROM MODEL YEAR 2002 - CODE 802	001	
20	A 140 545 35 28	. PIN BUSHING HOUSING INTAKE MANIFOLD [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001	
20	A 140 545 35 28	. PIN BUSHING HOUSING INJECTION VALVE [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	008	
25	A 203 545 05 28	. PLUG INTAKE MANIFOLD [810] FROM MODEL YEAR 2001 - CODE 801	001	
25	A 203 545 05 28	. PLUG INJECTION VALVE [810] FROM MODEL YEAR 2001 - CODE 801	008	
30	A 210 540 80 81	. PIN BUSHING HOUSING IGNITION COIL [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	008	
30	A 210 540 80 81	. PIN BUSHING HOUSING CYLINDER CUT-OUT SYSTEM [810, 811] FROM MODEL YEAR 2001 - CODE 801	002	
30	A 203 545 30 28	. PIN BUSHING HOUSING CAMSHAFT POSITION SENDER UNIT	001	
30	A 203 545 30 28	. PIN BUSHING HOUSING IGNITION COIL [810] FROM MODEL YEAR 2001 - CODE 801	008	
35	A 000 545 60 80	. GASKET	NB	
40	A 140 545 47 28	. PIN BUSHING HOUSING PRESSURE CONVERTER [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001	
45	A 203 545 34 28	. PIN BUSHING HOUSING PRESSURE CONVERTER [810] FROM MODEL YEAR 2001 - CODE 801	001	
50	A 005 545 66 26	. PIN BUSHING HOUSING INTAKE MANIFOLD PRESSURE SENSOR [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001	
55	A 210 540 21 81	. PIN BUSHING HOUSING INTAKE MANIFOLD PRESSURE SENSOR [810] FROM MODEL YEAR 2001 - CODE 801	001	
70	A 000 540 27 05	. CABLE HARNESS	NB	

70	A 000 540 27 05	. CABLE HARNESS REPAIR SOLUTION CONTACTING 1.0 MM2 [774] CONNECTORS MUST ALSO BE ORDERED IN ACCORDANCE WITH THE...	NB
70	A 000 540 28 05	. CABLE HARNESS REPAIR SOLUTION CONTACTING 2.5 MM2 [774] CONNECTORS MUST ALSO BE ORDERED IN ACCORDANCE WITH THE...	NB
75	A 220 545 94 28	. PLUG ENGINE CONTROL MODULE [810] FROM MODEL YEAR 2001 - CODE 801	001
80	A 014 545 93 28	. PIN BUSHING HOUSING KNOCK SENSOR [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	002
83	A 203 545 39 28	. PLUG KNOCK SENSOR [810] FROM MODEL YEAR 2001 - CODE 801	002
90	A 011 545 81 26	. CONTACT SPRING 0.5-1.0 MM2	NB
100	A 140 540 33 81	. PIN BUSHING HOUSING FINAL CONTROL ELEMENT IDLING-SPEED CONTROL [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001
110	A 003 545 48 26	. ROUND PIN BUSHING 1.0 MM2	NB
113	A 210 540 36 81	. PIN BUSHING HOUSING FINAL CONTROL ELEMENT IDLING-SPEED CONTROL [810] FROM MODEL YEAR 2001 - CODE 801	001
116	A 000 540 26 05	. CABLE HARNESS REPAIR SOLUTION CONTACTING 0.75 MM2 [774] CONNECTORS MUST ALSO BE ORDERED IN ACCORDANCE WITH THE...	NB
120	A 168 545 30 28	. PIN BUSHING HOUSING CRANKSHAFT POSITION SENDER UNIT	001
120	A 168 545 30 28	. PIN BUSHING HOUSING ALTERNATOR [820] FROM MODEL YEAR 2002 - CODE 802	001
130	A 013 545 15 26	. CONTACT SPRING 0.5-1.0 MM2	NB
140	A 210 540 20 81	. PIN BUSHING HOUSING REFRIGERANT TEMPERATURE SENSOR	001
140	A 210 540 20 81	. PIN BUSHING HOUSING CLUTCH VACUUM VALVE AIR PUMP	001
140	A 210 540 20 81	. PIN BUSHING HOUSING REFRIGERANT COMPRESSOR	001
150	A 210 540 21 81	. PIN BUSHING HOUSING OIL SENSOR	001
160	A 220 540 06 81	. PIN BUSHING HOUSING OIL PRESSURE GAUGE SENDER UNIT [810, 811] FROM MODEL YEAR 2001 - CODE 801	001
180	A 000 540 25 05	. CABLE HARNESS REPAIR SOLUTION CONTACTING 0.5 MM2 [774] CONNECTORS MUST ALSO BE ORDERED IN ACCORDANCE WITH THE...	NB
185	A 000 545 87 80	. BLIND PLUG	NB
200	A 000 540 46 05	. CABLE HARNESS REPAIR SOLUTION CONTACTING 0.75 MM2 [774] CONNECTORS MUST ALSO BE ORDERED IN ACCORDANCE WITH THE...	NB
209	A 210 545 14 30	. SHELL ENGINE CONTROL MODULE [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001
212	A 002 545 27 40	. PIN BUSHING HOUSING ENGINE CONTROL MODULE [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001
215	A 002 545 28 40	. PIN BUSHING HOUSING ENGINE CONTROL MODULE [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001

220	A 001 545 87 40	. PLUG HOUSING ENGINE CONTROL MODULE [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001
230	A 001 545 88 40	. PLUG HOUSING ENGINE CONTROL MODULE [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001
240	A 001 545 13 03	. CAP CONTROL-UNIT PLUG-CONNECTION [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001
250	A 210 545 05 30	. SHELL CONTROL-UNIT PLUG-CONNECTION [801] UP TO THE END OF MODEL YEAR 2000 - CODE 800	001
253	A 168 545 08 28	. PLUG HOUSING ENGINE CONTROL MODULE [810] FROM MODEL YEAR 2001 - CODE 801	001
280	A 011 545 81 26	. CONTACT SPRING 0.5-1.0 MM2	NB
280	A 004 545 53 26	. FLAT PIN BUSHING 1.5-2.5 MM2	NB
286	A 168 545 07 28	. PLUG HOUSING ENGINE CONTROL MODULE [810] FROM MODEL YEAR 2001 - CODE 801	001
290	A 220 545 46 28	. PIN BUSHING HOUSING AIR-MASS SENSOR	001
305	A 000 545 79 80	. BLIND PLUG	NB
310	A 000 545 25 46	. BOOT TO 220 545 46 28	001
310	A 000 545 25 84	. PLUG CAP TO 203 545 30 28	001
315	A 000 545 31 84	. BOOT TO 220 545 46 28	001
320	A 000 540 38 05	. CABLE HARNESS REPAIR SOLUTION CONTACTING 0.75 MM2 [774] CONNECTORS MUST ALSO BE ORDERED IN ACCORDANCE WITH THE...	NB
330	A 011 545 71 28	. PIN BUSHING HOUSING AIR INJECTION	001
340	A 003 545 26 26	. ROUND PIN BUSHING 4 MM2	NB
350	A 220 545 69 28	. PIN BUSHING HOUSING CO-DRIVER'S AIR BAG	001
360	A 013 545 15 26	. CONTACT SPRING 0.5 - 1.0 MM2	NB
360	A 013 545 16 26	. CONTACT SPRING 1.0 - 2.5 MM2	NB
370	A 168 545 01 28	. PIN BUSHING HOUSING CO-DRIVER'S AIR BAG 1-POLIG	001
380	A 000 540 58 05	. CABLE HARNESS REPAIR SOLUTION CONTACTING 6.0 MM2 [774] CONNECTORS MUST ALSO BE ORDERED IN ACCORDANCE WITH THE...	NB
390	A 004 545 20 26	. PIN BUSHING HOUSING ALTERNATOR [811] UP TO THE END OF MODEL YEAR 2001 - CODE 801	001
400	A 002 545 94 26	. PIN BUSHING 0.5-1.5 MM2	NB
463	A 001 540 24 81	. PLUG HOUSING OXYGEN SENSOR [810] FROM MODEL YEAR 2001 - CODE 801	002
470	A 000 540 42 05	. CABLE HARNESS REPAIR SOLUTION CONTACTING 1.0 MM2 [774] CONNECTORS MUST ALSO BE ORDERED IN ACCORDANCE WITH THE...	NB
510	A 002 545 52 01	. FUSE BOX 1-FACH	001
520	A 004 545 52 26	. CONTACT SPRING FUSE BOX 1.5 - 2.5 MM2	NB
530	N 072581 000305	. FUSE 15A	001

533	A 000 546 03 80	. CABLE GUIDE	001
540	A 220 997 09 81	. GROMMET	001
543	A 001 546 99 41	SOLDERING END CUPS GREEN 0.7-2.4 MM2	NB
543	A 002 546 00 41	SOLDERING END CUPS RED 2.0-4.0 MM2	NB
543	A 002 546 01 41	SOLDERING END CUPS BLUE 3.5-8.0 MM2	NB
543	A 002 546 11 41	SOLDERING END CUPS YELLOW 7.5-12.0 MM2	NB
546	A 002 546 13 41	CABLE CONNECTOR 0.5 MM2	NB
546	A 002 546 14 41	BUTT CONNECTOR 0.8 MM2	NB
546	A 002 546 15 41	BUTT CONNECTOR 1.3 MM2	NB
546	A 002 546 16 41	BUTT CONNECTOR 2.0 MM2	NB
580	A 001 995 85 01	CLAMP CABLE RAIL	001
590	N 007976 004302	TAPPING SCREW	001
600	A 001 997 83 90	CABLE TIE	NB
610	A 000 995 44 14	BRACKET AT TIMING CASE COVER	NB
620	A 220 546 18 43	BRACKET ELECTRONIC GAS ACTUATOR  [810] FROM MODEL YEAR 2001 - CODE 801	001