

1999 – 2003 S Class amplifier pin out

<u>TERMINAL</u>	<u>FUNCTION</u>	<u>DESCRIPTION</u>
1	INPUT	MIC +
2	SHIELD	MIC SHIELD
3	INPUT	MIC -
4	OUTPUT	LINE OUT 3+
5	OUTPUT	LINE OUT 6+
6	CONTROL	TEST MODE
7	OUTPUT	LINE RETURN
8	I/O	WAKEUP
9	POWER	GROUND
10	OUTPUT	Not Used
11	OUTPUT	SPKR 8-
12	OUTPUT	Not Used
13	OUTPUT	SPKR 1+
14	OUTPUT	SPKR 2-
15	OUTPUT	SPKR 4-
16	OUTPUT	SPKR7+
17	OUTPUT	SPKR5-
18	OUTPUT	Not Used
19	OUTPUT	SPKR 8+
20	OUTPUT	Not Used
21	OUTPUT	SPKR1-
22	OUTPUT	SPKR2+
23	OUTPUT	SPKR4+
24	OUTPUT	SPKR7-
25	OUTPUT	SPKR5+
26	POWER	BATTERY+

SPKR 1 = Left Front Door Speakers
SPKR 2 = Right Front Door Speakers
SPKR4 = Left Rear Door Speakers
SPKR5 = Right Rear Door Speakers
SPKR7 = Center IP Speaker
SPKR8 = Rear Shelf Woofer