



P88.10-2007-09

1a Inner fender
1b Inner fender

2 Nut
3 Screw

4 Screw
5 Sheet metal nut

	Removal, installation		
1 	Remove front wheel		AP40.10-P-4050Z
2	Unscrew screws (3) and (4)		
3	Unscrew nuts (2)		
4	Remove inner fender (1a) and (1b)	Installation: Pay attention to proper seating	
5	Install in opposite order		