



GF54.15-P-1257-03LE Relay assignment of fuse and relay box in left side of engine compartment GF

N10/1 Front SAM control unit with fuse and relay module  
X Direction of travel



P54.15-2760-05



P54.15-2760-05

| Socket | Designation                               |
|--------|---|
| A      | Air pump relay (N10/1kA)                  |
| B      | Air suspension compressor relay (N10/1kB) |
| C      | Terminal 87 relay, engine (N10/1kC)       |
| D      | Terminal 15 relay (N10/1kD)               |
| R      | Terminal 87 relay, chassis (N10/1kE)      |
| F      | Fanfare horn relay (N10/1kF)              |
| G      | Terminal 15R relay (N10/1kG)              |
| H      | Circuit 50 relay, starter (N10/1kH)       |
| J      | Circuit 15 relay, starter (N10/1kJ)       |
| K      | Wiper park heater relay (N10/1kK)         |