
GF54.15-P-1257-04SK	Relay assignment of fuse and relay box in	⊯ GF
	trunk	

Relay assignment for rear SAM control unit with fuse and relay module (N10/2)

1 to 20 Position for fuses

N10/2 Rear SAM control unit with fuse and relay module

A up to H plug position for relay



P54.15-2550-03

Вау	Relay	Designation
Α	N10/2AC	Fuel pump relay
В	N10/2kB	VICS relay (only)
С	N10/2kC	Reserve 2 relay
D	N10/2kD	Reserve 1 relay
E	N10/2KE	Rear window defroster relay
F	N10/2kF	Circuit 15R, relay 1
G	N10/2kG	Fuel filler cap polarity change 1 relay
Н	N10/2kH	Fuel filler cap polarity change 2 relay