
MODEL	216, 221
	with electrohydraulic power steering (EHPS)

1	Screw
2	Screw
3	Screw
4	Bracket
5	Screw
6	Pressure line D1
7	Electrical connector
8	Nut
9	Feed lineZ1
A91/1	Electrohydraulic power steering



P46.30-2292-06

isk of injury to skin or eyes from hydraulic hid spraying out under pressure. Risk of pisoning from swallowing hydraulic fluid. Dotes on bolted connections with self tapping rews formation on preventing damage to ectronic components due to electrostatic scharge Disconnect battery ground cable otes on battery	Depressurize hydraulic system completely before starting any work on it. Wear protective clothing and safety glasses.	AS00.00-Z-0013-01A AH00.00-P-0007-01SF AH54.00-P-0001-01A
formation on preventing damage to ectronic components due to electrostatic scharge Disconnect battery ground cable		
ectronic components due to electrostatic scharge Disconnect battery ground cable		AH54.00-P-0001-01A
otes on battery		AR54.10-P-0003SX
stor on sationy		AH54.10-P-0001-01A
pen engine hood		
Extract oil from power steering expansion servoir	 Before opening the hydraulic system, thoroughly clean the area surrounding the separation point. Even the smallest dirt particles, introduced into the hydraulic components, can lead to malfunctions and a total failure of the hydraulic system. Hand pump 	
Detach right front wheel		AP40.10-P-4050SX
emove front section of right wheelhouse trim front fender		
Remove screws/bolts (1, 2), unfasten screw/ lt (3) and turn electrohydraulic power eering (A91/1) outwards	MODEL 216 (except 216.376/377/379) without CODE 487 (Active Body Control (ABC)) MODEL 221 with ENGINE 156, 157, 272, 273, 275, 276, 278 without CODE 487 (Active Body Control (ABC))	*BA46.30-P-1014-01F
		without CODE 487 (Active Body Control (ABC)) MODEL 221 with ENGINE 156, 157, 272, 273, 275, 276, 278 without CODE 487 (Active Body Control

8	Detach pressure line D1 (6), to do so remove screw (5) and seal connections	Nm	*BA46.30-P-1016-01F
		MODEL 216 (except 216.376/377/379) without CODE 487 (Active Body Control (ABC)) MODEL 221 with ENGINE 156, 157, 272, 273, 275, 276, 278 without CODE 487 (Active Body Control (ABC))	*129589009100
9	Detach feed line Z1 (9) from electrohydraulic power steering (A91/1) and seal connections		AR46.25-P-3015SXH
		S Record plug	*129589009100
10	Detach electrohydraulic power steering (A91/1) from holder (4), to do so remove nuts (8)	i Check fasteners and replace if necessary.	
		Nm	*BA46.30-P-1015-01F
		MODEL 216 (except 216.376/377/379) without CODE 487 (Active Body Control (ABC)) MODEL 221 with ENGINE 156, 157, 272, 273, 275, 276, 278 without CODE 487 (Active Body Control (ABC))	
11	Install in the reverse order		
12	Fill power steering pump and bleed		AR46.30-P-0010SX
13	Read out fault memory using STAR DIAGNOSIS, delete if necessary and check electrohydraulic power steering (A91/1) for current flashware		
⊯≆ A D			AD00.00-P-2000-04A
14	Teach-in electrohydraulic power steering (A91/1) using STAR DIAGNOSIS	When replacing electrohydraulic power steering (A91/1)	
	Risk of accident from vehicle starting off by itself when engine running. Risk of injury (bruises and burns) resulting from working on the engine while it is being started or when it is running.	Secure vehicle to prevent it from starting off by itself. Wear closed and snug-fitting work clothes. Do not touch hot or rotating parts.	AS00.00-Z-0005-01A
15	Test run engine and check that steering system is not leaking and is functioning correctly		

Nm Power steering pump

Number	Designation		except CODE 487 (Active Body	MODEL 221 with ENGINE 156, 157, 272, 273, 275, 276, 278 except CODE 487
BA46.30-P-1014-01F	Bolt, power steering pump bracket (EHPS) to body	Nm	17	17

Nm Power steering pump

Number	Designation		except CODE 487	MODEL 221 with ENGINE 156, 157, 272, 273, 275, 276, 278 except CODE 487
BA46.30-P-1016-01F	Bolt, high-pressure line to power steering pump (EHPS)	Nm	18	18

Nm Power steering pump

Number	Designation		except CODE 487 (Active Body	MODEL 221 with ENGINE 156, 157, 272, 273, 275, 276, 278 except CODE 487
BA46.30-P-1015-01F	Nut, power steering pump (EHPS) to bracket	Nm	9	9

