


**MODEL 221.0 /1, 216.3**  
**with CODE (889) Keyless Go**  
**up to Model Year 8**

**Shown on model 221.0**

*A2/35 Trunk Keyless Go antenna*

**Location**

The trunk Keyless Go antenna is located on the bracket for the rear SAM control unit with fuse and relay module (N10/2) in the trunk.



P82.62-3088-04


**Model 216.3**

*A2/39 Left door Keyless Go antenna*

*A2/41 Right door Keyless Go antenna*

**Location**

The left door Keyless Go antenna and the right door Keyless Go antenna are located behind the door trim of the respective door.



P80.61-2215-04


**Model 221**

*A2/39 Left rear door Keyless Go antenna*

*A2/41 Right rear door Keyless Go antenna*

**Location**

The left rear door Keyless Go antenna and the right rear door Keyless Go antenna are located behind the door trim of the respective rear door.



P82.62-3087-04

**Illustrated on model 221**

*A2/60 Center console Keyless Go antenna*

**Location**

The center console Keyless Go antenna is located under the center console in the area of the turn/push control (A40/9s11).




P82.62-3086-04

**Model 216.3**

*A2/61 Interior Keyless Go antenna*

**Location**

The interior Keyless Go antenna is located under the rear center console in the area of the air outlet vent.



P80.61-2216-04

## Model 221

A2/61 Interior Keyless Go antenna

### Location

The interior Keyless Go antenna is located under the rear seats.



P82.62-3089-04

### Tasks

At the request of the Keyless Go control unit (N69/5), the Keyless Go antennas transmit a wake-up and locating signal for the transmitter key (A8/1).