



P20.40-2144-08

- 1 Fan box
2 Electrical connector
3 Electrical feed line

- 4 Bolts
5 Weather strip

- M4/7 Engine and AC electric suction fan with integrated control

|   | Remove/install | | |
|--|---|---|--------------------|
| | Risk of injury to skin and eyes caused by handling hot or glowing objects. | Wear protective gloves, protective clothing and safety glasses. | AS00.00-Z-0002-01A |
| 1 | Switch off ignition | | |
| 2 | Remove engine trim panel | | AR01.10-P-2405SXI |
| 3.1 | Remove engine intake air ducts on the right and left | With engine 642 | |
| 3.2 | Remove engine vacuum duct | With engine 651 | |
| 4 | Remove edge stripping (5) in the area of the radiator crossmember | | |
| 5 | Disconnect electrical connector (2) | | |
| 6 | Remove electrical feed line (3) from fan shroud (1) | | |
| 7 | Remove clamps on the left and right on fan shroud (1) | | |
| 8 | Remove fan shroud (1) together with engine and air conditioning electric suction fan with integrated control (M4/7) upwards | | |
| 9 | Install in the reverse order | | |