
ENGINES 272, 273 in MODEL 221 ENGINES 273 in MODEL 216



P20.10-2192-08

## Shown on engine 273

1 Upper coolant hose 2a Screw/bolt 3 Pulley

1aO-ring2bO-ring2Coolant thermostat housing2cSealY110Three-disk thermostat valve

## **Modification notes**

27.2.12	Reference to the altered version of the poly-V belt, added	Step 5	BT13.20-P-1000-01SXH

XX	Remove/install		
1	Switch off ignition		
2	Drain coolant at radiator		AR20.00-P-1142SX
(!)	Notes on coolant		AH20.00-N-2080-01A
3	Remove left engine intake air duct and front engine cover	See Remove air filter housing.	AR09.10-P-1150SX
4.1	Detach top coolant hose (1) from coolant thermostat housing (2) and place it on the side	Vehicles without 4MATIC	
		i Installation: Replace O-ring (1a).	
4.2	Remove coolant pipe	Vehicles with 4MATIC	
		See "Removing power steering expansion reservoir".	AR46.25-P-1000SX
5	Remove poly-V belt and guide pulley (3)	Except model 221.095/ 195 with a twin belt drive	AR13.20-P-0001SX
<b>⊯</b> BT	Version of the poly-V belt altered	Model 221.095 / 195	BT13.20-P-1000-01SXH
6	Unlatch electrical connector at three-disk thermostat valve (Y110) and disconnect		
7	Remove screw/bolts (2a, 2 pieces)	Nm	*BA20.10-P-1003-01U
8	Pull out coolant thermostat housing (2) with coolant thermostat from timing case cover	The coolant thermostat must not be taken out of the coolant thermostat housing (2) as it can get damaged in the process.	
		installation: Replace gasket (2b) and Oring (2c).	
9	Install in the reverse order		
<b>4</b>	Checking		
	Risk of accident caused by vehicle starting off by itself when engine is running. Risk of injury caused by contusions and burns during starting procedure or when working near the engine as it is running	Secure vehicle to prevent it from moving by itself.  Wear closed and snug-fitting work clothes.  Do not touch hot or rotating parts.	AS00.00-Z-0005-01A
10	Conduct engine test run and check engine for leaks		

Number	Designation	Engine 272	Engine 273
BA20.10-P-1003-01U	Screw/bolt, coolant thermostat housing to timing Nm case cover	25	25