

**i** The locations in the following work description refer to the stowage box cover (1) installed from the left side. Initial position for installing stowage box cover (1) illustrated as in figure: Upper button (2) and lower button (3) are "locked" in position. The upper set-up retainer (4) and lower set-up retainer (5) are extended.



P68.20-3309-06

- 1.1 Press lock-up button (6) and press upper set-up retainer (4) and release.

**i** When the upper set-up retainer (4) is pressed and the upper button (2) is in the "locked" position.

- 2.1 Press lock-up button (6) and press lower set-up retainer (5) and release.

**i** When the lower set-up retainer (5) is pressed and the lower button (3) is in the "locked" position.