



P83.50-2128-08

- 1 Rear air conditioner housing
- 2 Electrical line
- 3 Electrical connector
- 4 Bolts
- 5 Electrical connections

- M2/1 Rear blower motor
- N29/2 Rear air conditioning electronic blower controller
- X64/10 Rear blower intermediate connector

	Remove/install		
1	Remove center console	Model 221 up to 31.5.09 except for code (800) Model year 2010 Model 221 as of 1.6.09 or with code (800) Model year 2010	AR68.20-P-2000SX AR68.20-P-2000SXH
2	Detach rear blower intermediate connector (X64/10), then release and remove remaining connectors on rear air conditioner housing (1)		
3	Expose electrical line (2)		
4	Detach electrical connector (3) on rear air conditioning electronic blower controller (N29/2)		
5	Remove rear blower motor (M2/1) from rear air conditioner housing (1)		
6	Detach electrical connections (5) on rear blower motor (M2/1)		
7	Remove rear air conditioning electronic blower controller (N29/2) from rear blower motor (M2/1)	When replacing rear blower motor (M2/1).	
8	Install in the reverse order		