

- Parts list -

Vehicle	WDD2210221A283482 (63W)	320/350	
Color	197 - OBSIDIANSCHWARZ - METALLICLACK	Equipment	204 - LEDER - BRAUN
Assortment class	PC	Group	82 ELECTRICAL SYSTEM
Sub-group	310 LOUDSPEAKER		





Image ID: drawing_B82310000004

Item	Part number	Designation/additional information	Qty
10	A 221 820 02 02	SPEAKER Tweeter, in left rear door	1
10	A 221 820 02 02	SPEAKER Tweeter, in right rear door	1
20	A 221 820 31 02	SPEAKER Lower left rear door	1
20	A 221 820 31 02	SPEAKER Lower right rear door	1
30	N 910002 004124	RIVET MOUNTING, LOUDSPEAKER	3
30	N 910002 004124	RIVET MOUNTING, LOUDSPEAKER	3
40	A 221 820 02 02	SPEAKER LEFT AND RIGHT FRONT TWEETER	1
40	A 221 820 02 02	SPEAKER LEFT AND RIGHT FRONT TWEETER	1
50	A 221 820 29 02	SPEAKER ON DOOR ARRESTER BOTTOM, RIGHT	1
50	A 221 820 28 02	SPEAKER ON DRIVER DOOR BOTTOM, LEFT	1
60	N 910002 004124	RIVET MOUNTING, LOUDSPEAKER	4
60	N 910002 004124	RIVET MOUNTING, LOUDSPEAKER	4
70	A 221 820 24 02	SPEAKER HAT TRAY	1

Parts Information

Item	Part number	Designation/additional information	Qty
100	A 221 820 22 02	SPEAKER IN INSTRUMENT PANEL CENTER Code: -810+-811;	1
110	N 000000 000522	TAPPING SCREW MOUNTING, LOUDSPEAKER; 4.2X16	3
120	A 221 689 13 08 8L35 	COVER CENTER FILL Code: -498;	1
150	A 123 899 00 97	FELT STRIP LOUDSPEAKER LINE TO REAR SHELF; 55X70X3MM	1
900	A 210 545 65 28	PLUG FRONT DOOR SPEAKER H4/5, H4/6; 6-PIN	2
901	A 011 545 81 26	CONTACT SPRING FRONT DOOR SPEAKER; 0.5-1.0 MM2 JPT	NB
902	A 030 545 28 28	PLUG LEFT AND RIGHT FRONT TWEETER H4/5,H4/6,H4/68,H4/69; 2-PIN MQS	2
902	A 030 545 28 28	PLUG LEFT AND RIGHT REAR TWEETERS H4/3,H4/4; 2-PIN MQS	2
903	A 000 540 46 05	ELECTRIC LINE LEFT AND RIGHT FRONT TWEETER; 0.75 MM2 MQS SN [T774] CONNECTORS MUST ALSO BE ORDERED IN ACC. WITH THE TOTAL CABLE CROSS-SECTION TO BE CONNECTED. SEE WIS FOR REPAIR INSTRUCTIONS. =====	NB
903	A 000 540 46 05	ELECTRIC LINE LEFT AND RIGHT REAR TWEETERS; 0.75 MM2 MQS SN [T774] CONNECTORS MUST ALSO BE ORDERED IN ACC. WITH THE TOTAL CABLE CROSS-SECTION TO BE CONNECTED. SEE WIS FOR REPAIR INSTRUCTIONS. =====	NB
904	A 210 545 63 28	RECEPTACLE HOUSING LOUDSPEAKER REAR LEFT AND RIGHT H4/3,H4/4; 2-PIN JPT	2
905	A 011 545 81 26	CONTACT SPRING LOUDSPEAKER REAR LEFT AND RIGHT; 0.5-1.0 MM2 JPT	NB
906	A 030 545 28 28	PLUG BLACK CENTERFILL SPEAKER H4/27; 2-PIN MQS	1
907	A 000 540 46 05	ELECTRIC LINE BLACK CENTERFILL SPEAKER H4/27; 0.75 MM2 MQS SN [T774] CONNECTORS MUST ALSO BE ORDERED IN ACC. WITH THE TOTAL CABLE CROSS-SECTION TO BE CONNECTED. SEE WIS FOR REPAIR INSTRUCTIONS. =====	NB
910	A 210 545 65 28	PLUG BASS BOX H4/17; 6-PIN	2
911	A 004 545 53 26	CONTACT SPRING BASS BOX H4/17; 2.5 MM2 JPT	NB