

<b>Item</b>	<b>Designation</b>	<b>Coordinates</b>
<b>A13</b>	Electric parking brake control unit	4A 12A 18A
<b>N10/1</b>	Front SAM control unit with fuse and relay module	6L
<b>N10/2</b>	Rear SAM control unit with fuse and relay module	2L
<b>N93</b>	Central gateway control unit	19L
<b>S76/15</b>	Electric parking brake switch	14L
<b>U200</b>	Valid for TELE AID	8E
<b>U634</b>	Not valid for TELE AID	6E
<b>U777</b>	Valid for navigation	8F
<b>W34</b>	Ground (left footwell)	10L
<b>W54/3</b>	Ground (left rear wheelhouse)	4E
<b>X18</b>	Cockpit wiring harness and FFS [RBA] connector	13F
<b>Z81/5</b>	Circuit 58d COC connector sleeve	8G
<b>Z81/5z1</b>	Circuit 58d COC connector sleeve	8G
<b>CAN G</b>	Front end CAN	18K